



Push-pull tone pot:



Neck Pickup Wires:	Bridge Pickup Wires:
A - Green	E - Green
B - Red	F - Red
C - White	G - White
D - Black	H - Black

Operating Instructions
 3-way toggle pickup switch:
 Position 1 (down) - Treble Pickup
 Position 2 - Treble and Bass Humbucking Pickups
 Position 3 (up) - Bass Pickup
 Push-Pull Tone Pot:
 Down - Humbucker mode
 Up - Single Coil mode



Models: SE Chris Robertson