



Operating Instructions
 3-way blade pickup switch:
 Position 1 (down) - Treble Pickup
 Position 2 - Treble and Bass Humbucking Pickups
 Position 3 (up) - Bass Pickup
 Push-Pull tone pot:
 Down - Humbucking mode
 Up - Single coil mode

Models: SE Mark Holcomb